

Installation of

QCT 4

Online Update

JUKI




Copyright December 20, 2017
Jim Bagley, GraceWood, Inc
(Reproduction Prohibited)
Version 1.1

Preparing to install the On-line Update

Follow the instructions below if you do not know how to connect your tablet to the Internet

- To connect to the Internet, swipe in from the right on your tablet. Click on **All Settings**.



- Click on **Network & Internet**.



Network & Internet
Wi-Fi, airplane mode, VPN


Status

Network status



Not connected

You aren't connected to any networks.


 Troubleshoot

[Show available networks](#)

- Under Status Click on the link that says **Show available networks**.

The list of available wi-fi networks will show up. Locate your local wi-fi Connection, click on it. If you have never connected to this network it will prompt you for your wi-fi password. Enter in your password and click on **Connect**.


If your Wi-Fi button is greyed out, click on the button to enable the Wi-Fi. If your tablet/Laptop has a dedicated button to enable Wi-Fi you must turn that on.



Before beginning the update, please do the following:

- Close all other programs before launching your software.
Make sure your Windows software is updated prior to installing the Quilter's Creative Touch software upgrade.

- Swipe in from the right and click on the **All Settings** button.



- Click on **Update & Security**.



- Click **Check for Updates**.

Windows Update

Update status



Your device is up to date. Last checked: Yesterday, 4:51 PM

Check for updates


- Allow the tablet to install the updates, this may require several restarts of your tablet to complete. Now you can proceed with your **Quilter's Creative Touch** software installation.

Online Update to Quilter's Creative Touch 4


From the main window of the program, click on **Help**.




From the **Help Menu** window, click on **Software Updates**.




From the **What would you like to do?** window, click on **Update now from on-line Files**.



From the **Select to begin updating...**
Click on **1. Update - Version 4.01.XX**




The **Downloading File...** window
will automatically close once the
file has completed downloading.




User Account Control will now prompt
you **Do you want to allow this app
from an unknown publisher to make
changes to your device?**


Click on **Yes**.



On the **Welcome to the
Quilter's Creative Touch Setup
Wizard** window click on **Next >**.




On the **License Agreement** window click on **I accept the agreement** and click **Next >**.




On the **Select Destination Location** window.

*** Do not change the default destination location.**




On the **Folder Exists** window click **Yes**.




On the **Select Start Menu Folder** window * click **Next >**.


* **Do not change the default Start Menu Folder name.**




On the **Select Additional Tasks** window leave the **Create a desktop icon** checked and click **Next >**.




On the **Ready to Install** window click **Install**.





The **Installing** window will show the progress of the installation.




On the **Completing the Quilter's Creative Touch Setup Wizard** window click on **Finish** to exit Setup.




Double click the start icon on your desktop to launch the program, the installation of files and directories will complete.




Next you will be prompted "Are you going to use this device (this computer or tablet, etc) with your automated sewing system?" Click on **Yes**.




On the **USB Driver Load** window click on **Load Drivers**.




Double click on the **CDM21216_Setup** file.




On the **FTDI CDM Drivers** window click on **Extract**.




On the **Welcome to the Device Driver Installation Wizard!** window click on **Next**.




On the **License Agreement** window click on **I accept this agreement** then click **Next**.




On the **Completing the Device Driver Installation Wizard** window click on **Finish**.




Click on the **X** in the upper right hand corner of the File Explorer.



Click on **OK**.




On the **Re-start Program** window click on **OK**.




Plug the USB cable from the Quilt Motion into the Tablet / Computer.


Double click on the shortcut for **Quilter's Creative Touch**.



You will be prompted about continuing in Simulation Mode. Click on **No**.



You should be prompted to make sure the needle is up and to center your carriage. Click **OK**.




You will need to Register your Software within the time limit defined.




Completing the Motor Firmware Update

Click on **Yes** to continue with the firmware update.




You will now be prompted to turn the sewing machine OFF. **Once the sewing machine is turned OFF**, then click **OK** to continue with the firmware update.



The **Firmware Load Button Push** window will appear.

The **OK** button and the **firmware update button** need to be pushed at the same time.




This may take a couple of tries. Start tapping the firmware update button and then try clicking on the **OK** button.


This is how the QuiltMotion will look under your carriage. Press the firmware button at the same time you are pressing OK on the prompt.



The moment you see these numbers counting down showing the lines remaining for the Motor Driver Update, **stop pressing the button**. Do not touch the carriage or the Tablet / Computer while it is completing this update.



You will now be prompted to **POWER CYCLE the motor carriage then turn the sewing machine back ON**. Click **OK**.




Once you have completed power cycling the carriage click on **Yes**.

You will now be prompted **The program will shut down. You will need to re-start it.** Click **OK**.


Double click the shortcut to launch **Quilter's Creative Touch 4**.



The software loading screen will now appear as the files are completing installation.




You are back on the main screen of the program and it is showing that you are connected.




Troubleshooting

Depending up the version of Windows you are running it is possible you may encounter an error that looks like this:


If you do get a message like this, click **OK**. This should close the program installer.




To restart the installation, click on the File Explorer icon on your taskbar:




This will open **File Explorer**. Locate **This PC** and click.




Locate the **(C:) Drive** and click. Double click on **Powered By QuiltCAD**.



Locate the **Updates** directory and double click.



In **Updates**, locate the **setupJKupdate_4.XX.XX_X-X-2018** file. Delete the file. Return to page 1 and proceed with the installation again.



If you have any questions or run into any problems please give us a call at
1-800-264-0644
select **Technical Support**.

